



Nett Technologies Inc.

2-6707 Goreway Drive, Mississauga, Ontario

Canada L4V 1P7

tel: 905.672.5453

fax: 905.672.5949

e-mail: sales@nett.ca

web: <http://www.nett.ca>

technical manual

NEES 200™

**Nett
Emissions
Eliminator
System**



Contents

Product Description	3
Overview	3
Applications.....	3
Principle of Operation	3
Item List & Part Numbers	5
Installation Instructions	6
Step 1: Installing the 3-Way Catalytic Muffler/Converter - Important Note.....	6
Step 2: Install the Electronic Control Unit (ECU)	8
Step 3: Install the Oxygen Sensor	8
Step 4: Install the Solenoid Valve	8
Step 5: Install the Vacuum Line	8
Step 6: Complete the Electrical Connections	10
Calibration	11
NEES 200™ Indicator Lights	11
Check Engine Light	11
O ₂ Sensor Light	11
Modulation Lights	11
Fuel System Set up Procedures	12
Idle operation	12
High load operation	12
Medium speed/load conditions.....	13
Troubleshooting	13
Detailed Troubleshooting Procedure	14



Product Description

Overview

The NEES 200™ is a digital air-to-fuel (A/F) ratio controller for gaseous fuelled, carbureted forklift truck engines. The NEES 200™ is designed for use with Nett® 3-way catalyst systems in closed-loop configurations. By precisely maintaining the optimal A/F ratio (also known as the stoichiometric A/F ratio) under all engine operating conditions, the unit maximizes emission reductions in the 3-way catalyst. The controller also reduces fuel consumption and increases engine life.

The controller incorporates an on board diagnostic system, which allows for constant monitoring of its operation and simplifies set-up. The combination of lights built directly into the unit provides an indication of the controller operation without the need for additional monitoring tools. The diagnostic functions include a power and failure light, a warm up and O₂ sensor light, and a set of lights to monitor the percentage of A/F ratio modulation. The unit also includes an optional, dashboard-mounted warning light to alert the operator in case of system failure and to prevent the release of excessive emissions.

Applications

The NEES 200™ system can control A/F mixtures on carbureted engines fueled by liquefied petroleum gas (LPG, “propane”, “propane-butane”) and by compressed natural gas (CNG).

It is primarily designed to work with air-valve type gaseous carburetor systems, including IMPCO, Woodward and equivalent products. The controller is also compatible with most venturi-type gaseous carburetors, such as Aisan, Beam, or Garretson.

The controller is not intended for use on engines with electronic fuel injection systems. Nett® 3-way catalysts can be installed on electronic fuel-injected engines in stoichiometric calibration without the need for modifications or an additional control unit.

Principle of Operation

Figure 1 shows the main functional components of the NEES 200™ system, including the electronic control unit (ECU), oxygen sensor, and solenoid valve. The oxygen (O₂) sensor, installed in the vehicle exhaust system upstream of the Nett® 3-way catalytic converter or catalytic muffler, continuously monitors the exhaust gas composition. Lean A/F mixtures produce exhaust gases of high oxygen concentration, while rich A/F mixtures produce exhaust gases with little or no oxygen. A feedback signal from the oxygen sensor is passed to the ECU, which controls the vehicle’s fuel system to maintain the optimal, stoichiometric A/F ratio.

A/F mixture control is achieved by biasing the diaphragm in the fuel regulator using vacuum taken from an area above the throttle in the fuel mixer. This vacuum signal is passed to the fuel regulator through the solenoid valve. ECU-controlled modulation of this valve determines the amount of vacuum signal that can pass to the regulator. The more vacuum passed to the regulator, the more restricted the flow of fuel and, consequently, the leaner the A/F mixture.



Since the A/F mixture can only be made leaner (as opposed to richer) by the described control mechanism, it is required that the vehicle's fuel system be calibrated to a rich mixture during the set up of the controller. Once installed and set up, as outlined in the set up procedures, the NEES 200™ controller leans the mixture, as may be required at different speed and load conditions, to maintain a stoichiometric A/F ratio.

Feedback air valves should be used with Impco carburetors for best control:

- model 100 carbs use Impco P/N: AV1-1447-2
- model 200 carbs use Impco P/N: AV1-1245-2




Figure 1. NEES 200™ Control System Schematic




Item List & Part Numbers

NEES 200™ - Dynamic Digital Air/Fuel Ratio Controller Assembly for LPG/CNG Engines, Nett Technologies P/N: AF-00200-KT-NEES2-00010

Items included in the NEES 200™ kit are listed in the following table.

Item	Description	P/N	Qty
1	NEES 200 Control Module	AF-00200-PT-MODUL-00010	1
2	Wiring Harness	AF-00200-PT-HRNSS-00010	1
3	Wire Loom (6' Split Loom)	AF-00200-PT-WLOOM-00010	1
4	Spade Connector	AF-00200-PT-WCONN-00010	2
5	Ring Connector	AF-00200-PT-WCONN-00020	1
6	Oxygen Sensor Connector	AF-00200-PT-HRNSS-00020	1
7	Oxygen Sensor	AF-00200-PT-OXSEN-00010	1
8	Solenoid Valve	AF-00200-PT-SOLND-00010	1
9	Clamp, 5/16 (Wiring)	AF-00200-PT-CLAMP-00010	1
10	Clamp, 5/16 (Vacuum Hose)	AF-00200-PT-CLAMP-00020	1
11	Foam Filter	Not Sold Separately	1
12	5/32" Vacuum Line	AF-00200-PT-PHOSE-00156	1
13	Vacuum Elbow (plastic)	AF-00200-PT-FTTNG-00060	1
14	Vacuum Fitting (brass)	AF-00200-PT-FTTNG-00010	1
15	Warning Light	AF-00200-PT-LIGHT-00010	1
16	Check Engine Decal	AF-00200-PT-DECAL-00010	1



Important: It is strongly recommended that the engine be serviced, and set to manufacturer's specifications prior to the installation of the NEES 200™ system. In particular, the intake air and fuel filter elements must be inspected and replaced or cleaned if needed.

Step 1: Installing the 3-Way Catalytic Muffler/Converter - Important Note

It is important that there are no leaks in the exhaust system upstream of the muffler/converter. U-Bolt style clamps should not be used as they do not provide a reliable seal. Nett Technologies recommends the use of 1" wide band-style clamps.



The chart below lists sizes and part numbers for several manufacturers who make this type of clamp. The following list shall not be construed in any way as an explicit endorsement by Nett Technologies Inc.

technical manual

Pipe Size (OD)	Clamps Inc.	Clamps Inc.	Donaldson	Nelson	Nelson	Walker
1.50"		BCE 150				
1.63"		BCE 158				
1.75"	NBC 175	BCE 175				
1.88"		BCE 188				
2.00"	NBC 200	BCE 200	J000204	90869A	900016A	
2.13"		BCE 213				
2.25"	NBC 225	BCE 225	J000205	90870A	900017A	
2.50"	NBC 250	BCE 250	J000206	90871A	900018A	
2.75"	NBC 275	BCE 275	J000207	90872A	900019A	
3.00"	NBC 300	BCE 300	J000200	90873A	900003A	
3.25"		BCE 325				
3.50"	NBC 350	BCE 350	J000201	90874A	900004A	
3.88"		BCE 388				
4.00"	NBC 400	BCE 400	J000202	90875A	90885A	35227
4.25"		BCE 425				
4.50"		BCE 450	J000208	90876A		
5.00"	NBC 500	BCE 500	J000203	90877A	90887A	35228
6.00"	NBC 600	BCE 600	J000209	90878A	90888A	33316

- Clamps Inc <http://www.clampsinc.com>
- Donaldson <http://www.donaldson.com>
- Nelson <http://www.nelsondiv.com>
- Walker/Tenneco <http://www.tenneco-automotivehd.com/>



Step 2: Install the Electronic Control Unit (ECU)

The unit can be installed in the engine compartment, under the dashboard, or on the dashboard for operator monitoring. The location should permit the wiring harness to reach the oxygen sensor and the solenoid valve.

Caution: Exposure to high temperatures can damage the ECU. When mounted in the engine compartment, the unit should be installed in a reasonably cool location, preferably at the opposite side of the engine relative to the exhaust manifold and at least 30 cm (12") away from exhaust piping.

Step 3: Install the Oxygen Sensor

The oxygen sensor must be installed into a threaded M18 port in the exhaust pipe or at the inlet to the catalytic converter/muffler. All Nett® 3-way catalytic mufflers for forklift trucks come with an oxygen sensor port pre-installed in the inlet section of the muffler. At the time of shipment, the port is plugged with a brass plug. Simply remove the plug and install the oxygen sensor in its place.

Caution: Exposure to high temperatures can damage the oxygen sensor or shorten its life. When mounted in the exhaust pipe, the unit should be placed at least 25 cm (10") away from the exhaust manifold.

Step 4: Install the Solenoid Valve

Secure the solenoid valve to the converter/regulator cover using one of the converter cover screws.

If the engine is to be operated in dusty environment, install the foam filter on the air port of the solenoid valve (it is the brass port of the solenoid located in the proximity to the electrical connections, as shown in Figure 2). Making sure that the port opening is not blocked, place a drop of adhesive on the brass port and place the foam filter over the port.

Step 5: Install the Vacuum Line

This step involves (1) the installation of the vacuum elbow into the fuel converter/regulator, (2) connecting the elbow with the solenoid valve, (3) installing the vacuum fitting in the mixer and (4) connecting the solenoid valve with the mixer vacuum. Solenoid valve ports are referenced in Figure 2 (on page 10).

(1) Locate the atmospheric vent on the converter, it will either be on the cover (IMPCO, Nolf's) or at the base of the converter (Aisan).

IMPCO, Nolf's - remove the vent screen, install the plastic vacuum elbow into the threaded port. Note that on some systems a balance line between the converter and the Mixer may exist which uses the atmospheric vent port. If it is installed, remove the fitting from the converter and install our fitting. Also check the section on mixers.

Aisan Standard System - tap the vent hole 1/8 N.P.T., install the plastic vacuum elbow

Aisan System with Resonator – Disconnect the vacuum hose from the resonator to the converter/regulator. Remove the press fit vacuum fitting from the converter. Tap the

hole 1/8 NPT, and install the plastic vacuum elbow. Remove the vacuum line from the resonator to the air inlet tube. Plug the hole in the air inlet tube. Disconnect the resonator from the machine and discard.


If possible, position the orifice downward to allow moisture which may accumulate in the line to drain. Note: Do not over-tighten (to avoid breaking the plastic thread).

(2) Cut sufficient length of the flexible vacuum hose and connect the vacuum elbow with the plastic vacuum port on the side of the solenoid valve (see Figure 2 on page 10).

(3) Identify a vacuum port in the mixer and install the vacuum fitting.

Air Valve Mixers:

IMPCO, Nolff's: These mixers have a predrilled port to access the air valve vacuum. This port is located in the area between the throttle and the mixer air valve. It is usually plugged by a small, chromium-plated screw (Impco PN S1-69). Simply remove the screw and install the included brass vacuum fitting. Note that if a balance line is installed it may use this port, if so remove and discard. On some mixers the balance line will hook into the upper mixer body, if so remove and discard it, and plug the port, see items 21, 56, 59 & 60 below.



Venturi mixers: Most venturi-type mixers (Aisan, Beam) have no predrilled vacuum ports. In such case, the mixer has to be drilled and tapped before the vacuum fitting can be installed. If possible, venturi vacuum should be used by drilling the mixer just underneath the venturi nozzle. Alternatively, the vacuum can be taken from the mixer throat at any place between the venturi and the throttle using a 7/32" drill bit. Tap the hole to 1/4" x 28 thread pitch and install the brass fitting supplied.

On Aisan mixers the location adjacent to the casting boss (right hand side) is preferred. On Aisan dual fuel systems drill the hole into the intake elbow of the power valve section to access the air valve vacuum.

Important: The source of vacuum must be from a point above the engine throttle. The controller works properly at vacuums between about 1 – 3 kPa (4 – 12" H₂O). Connecting the NEES 200™ to engine manifold vacuum will result in unstable operation and may result in serious loss of vehicle's drivability.



Cut sufficient length of the flexible vacuum hose and connect the vacuum fitting in the mixer with the remaining plastic vacuum port of the solenoid valve (see Figure 2).




Figure 2. Solenoid Valve Ports

Step 6: Complete the Electrical Connections

Once installed, the unit must be wired into the forklift 12V electrical system following the diagram below.




Figure 3. Electrical Connection Schematic

All electrical connections should be soldered and sealed. It is important to adequately pre-heat wires before applying solder. Cold solder joints may cause improper operation of the controller.

NEES 200™ Indicator Lights

The NEES 200™ electronic control unit is equipped with indicator lights, as illustrated in Figure 4. The lights allow for the initial calibration of the system, as well as for servicing and monitoring the engine operation throughout the life of the unit.




Figure 4. NEES 200™ Indicator Lights

Check Engine Light

This red color light illuminates on start-up, indicating that power is being supplied to the unit. After approximately 40 seconds the light turns off. If the controller is unable to maintain proper mixtures, the red light will come on and stay on indicating that engine maintenance and/or service is required. The failure light is triggered by rich conditions lasting longer than 1.5 - 2 minutes.

O₂ Sensor Light

This light is yellow on initial start up. After 40 seconds it becomes a monitoring light for the oxygen sensor. Green color indicates lean condition. Red color indicates rich condition. If the light is cycling steadily from green to red, it indicates proper control of the A/F mixture. The timing of A/F mixture changes should be about 1 – 2 seconds.

Steady lean condition (green) or a steady rich condition (red) indicates that the controller is unable to maintain the stoichiometric A/F ratio, signaling a problem with the engine and/or the controller system.

Modulation Lights

There are four orange lights indicating the modulation percentage of the solenoid valve. In fact, the NEES 200™ pulses the solenoid between “on” and “off” many times per second. The modulation percentage is a measure of the average voltage of the pulses sent to the valve and an indication of the amount of control the solenoid is exerting over the A/F mixture. A higher modulation value indicates that the valve is “more open” and more vacuum is passed to the fuel regulator in order to lean the A/F mixture.

It is normal for these lights to oscillate indicating changing modulation, as required to control the A/F mixture. Typically, modulation oscillates around 50%, however it



may change due to changing conditions, such as worn mixers, dirty air and/or fuel filters, etc. The frequency of oscillation should be about 0.5 – 1 cycle per second.

Steady modulation at either end-value indicates that the unit is unable to properly control the A/F mixture. For example, a 100% modulation indicates that the maximum amount of vacuum is being passed to the fuel regulator in an attempt to correct a rich condition. In a controllable system, this action should lean the mixture causing the modulation to decrease. However, if the system is not responding and the rich condition continues, the controller will remain in its 100% modulation state indefinitely.

Fuel System Set up Procedures

Since the controller can only lean the A/F mixture by restricting the flow of fuel in the regulator, it is necessary to adjust the vehicle’s fuel system to a rich condition after the installation of the NEES 200™ system. It is then the task of the controller to lean the mixture as may be required at different engine speed and load conditions or during transient operation.

The set up of the controller must be performed with the engine at proper operating temperature and at a high speed “Load” condition. This is accomplished by putting the hydraulics into bypass mode with the accelerator depressed fully. While holding the engine speed and load, adjust the power valve to attain proper oscillation between red and green on the O₂ (oxygen sensor) display light of the controller (see the calibration tip below.) At the same time, ensure that the modulation lights are at approximately 50%. If the display lights are within these guidelines the system is properly set up and no further adjustments are required.

Calibration Tip: In a properly calibrated system, the mixture oscillates between rich and lean at a frequency of about 0.5 – 1 cycle per second, as indicated by the oxygen sensor and solenoid modulation lights on the NEES 200™ unit.

In practice, there are three adjustment mechanisms, addressing the A/F mixture at different speed/load conditions, as follows.

Idle operation

A/F mixture composition at idling is controlled by the *idle air bypass adjustment screw*, which is located on the body of the mixer.

Note: Some venturi systems cannot be controlled at stoichiometric during idle due to insufficient venturi vacuum at low engine speed. This is usually acceptable, as idle emissions constitute a small percentage of the total forklift truck emissions.

High load operation

A/F ratio during high load operation is controlled by the *power adjustment screw*, which is located at the fuel inlet to the mixer.



Medium speed/load conditions

The A/F ratios at intermediate load conditions are determined in air-valve mixers by the valve shape. For best results, *mixers and/or air valves designated as “feedback” should be used with A/F mixture controllers.* Consult your fuel system supplier for part numbers.

Venturi mixers do not have a medium load mixture adjustment.

Troubleshooting

The following troubleshooting chart lists some possible problems related to the operation of the A/F mixture control system. Further tests may be required to diagnose catalytic converter problems using an appropriate exhaust gas analyzer.

Problem	Possible Cause	Action
Drivability problems, engine hesitation on rapid acceleration, fluctuation in engine speed.	The vacuum signal is too strong. The controller has been connected to engine manifold vacuum (i.e., vacuum from underneath the throttle).	Connect the controller to air valve or venturi vacuum (i.e., vacuum from above the throttle).
	The vacuum connection is correct, but the signal is still too strong for the vehicle’s fuel system.	Vacuum elbow installed in the atmospheric vent of the propane converter has a predrilled orifice (hole) of 1.5 mm (0.060”) diameter. Remove the elbow and enlarge the orifice by drilling to a 1.8 mm (0.070”) diameter. Reinstall the elbow.
Rich condition. The oxygen sensor light stays red, the solenoid modulation is 100%.	Dirty intake air cleaner element.	Remove the air cleaner and run the engine. If the A/F mixture returns to normal, replace the air cleaner element.
	Vacuum leaks into converter.	Verify that vacuum hoses are properly connected. Repair or reconnect hoses, as needed.
	Vacuum hose between the solenoid and converter has been incorrectly connected to the liquid side of the converter.	(Diagnosis: the engine quits when the solenoid to converter hose is removed.) Install the vacuum hose in the atmospheric vent port on the vapor side of the converter.
	Faulty mixer, or regulator, or solenoid valve.	Create a controlled vacuum leak into the mixer. If the oxygen light starts pulsing green/red, check the mixer, regulator, and verify that the solenoid valve is working.
	Faulty oxygen sensor.	Check the oxygen sensor signal (between the green and black wires) using a voltmeter. The voltage should be cycling between 0 and 1 V. If the voltage doesn’t cycle, install new oxygen sensor and re-test.
	Faulty electronic control unit.	Replace the controller.



Problem	Possible Cause	Action
Lean condition. Oxygen sensor light stays green for prolonged periods of time and/or during some engine conditions.	Dirty fuel filter.	Check and replace the fuel filter.
	Vacuum leaks into mixer.	Check vacuum hoses and connections.
	Mixer is not adjusted rich.	Create a rich condition by blocking the intake air cleaner or by injecting propane into a mixer vacuum port. If the A/F mixture returns to normal, adjust the mixer for rich mixture using its power and idle screws. If necessary, replace the standard lean valve by a feedback valve in the air valve mixer.
	Insufficient fuelling rate due to a mixer or converter/regulator problem.	Check the mixer and converter for proper operation. Fix or replace, as needed. You may also try using a lower pressure spring in the fuel regulator (e.g., replace the standard blue-coded spring with the orange spring in IMPCO mixers).
	Oxygen sensor problem	Check exhaust gas piping upstream of the sensor for air leaks, repair if necessary. Connect voltmeter to the oxygen sensor (green-black wire) and create a rich condition. If the oxygen sensor remains lean, replace it and re-test.
Faulty electronic control unit.	Replace the controller.	

Detailed Troubleshooting Procedure

Caution: Do not use a test light. Check voltages with a Digital or Analog multimeter. Make measurements with positive lead of meter, negative lead of meter to be attached to controller ground.

- 1) With key in the on position is there 12 volts to the controller? If not check the power wiring, otherwise go to step 2.
- 2) Check that the connection of the controller ground is good. Wire should be run to battery or main engine ground. If the ground is good go to step 3.
- 3) Is there 12 volts to the red wire on the fuel control valve solenoid (PN AF-00200-PT-SOLND-00010)? If yes go to step 4.
- 4) If the engine starts and then quits disconnect the vacuum hose at the converter. Restart the engine. If it runs properly check the plastic vent elbow (PN AF-00200-PT-FTTNG-00060) and make sure that the opening is not blocked. The vent hole should be between 0.060 and 0.080 inch diameter. If this does not fix the problem go to step 5.
- 5) Check the fuel control valve solenoid (PN AF-00200-PT-SOLND-00010) by blowing through the port that connects to the converter. Air should come out of the



port that the filter is attached to only. Apply 12 volts to the valve; plug the filter port and blow through the valve. Air should come out of the port that goes to the mixer vacuum. If the fuel control valve checks out then go to step 6.

6) If the controller is showing red on the O₂ sensor light when running induce a vacuum leak. If the light turns yellow this confirms that the O₂ sensor is working. Check to see why the engine is running rich (i.e. Plugged air filter, primary fuel pressure in the converter is too high, dirty air valve assembly in the mixer, idle or power valve set too rich). If there is still a problem with the system go to step 7.

7) If the O₂ light on the controller is yellow when running, induce more fuel and check if the light turns red. If so the O₂ sensor is working. Check to see why the engine is running lean (i.e. vacuum leak at intake manifold, PCV valve stuck open, exhaust leak before the O₂ sensor such as a blown exhaust manifold gasket, fuel tank installed incorrectly so that engine is running off vapor instead of liquid. If there is still a problem go to step 8.

8) When the engine is set up and running correctly the voltage at the blue wire on the fuel control valve will vary between 4 and 10 volts.

When the engine is set up and running correctly the voltage at the green wire from the O₂ sensor should vary between 0.1 to 0.9 volts.

Nett Technologies Inc. has a corporate policy of continuous product development. Specifications are subject to change without notice.